

# Application Guide

**Pfx** Counterpointe Pearlstone

## Getting Started

### Application Tips

Application Temperature: 50° - 85° F


Spread Rate: Up to 70-80 square feet per gallon. Depending on surface porosity and texture, size of pattern and method of application.

Drying Time: 2-4 Hours Depending on humidity and temperature  
Full film integrity at 7-10 days.

Ambient Light conditions will have an effect on the final appearance. Use proper lighting while applying.

### Mock Up Wall


Zolatone recommends applying a mock up area to be approved by the specifier before beginning general application.



## A. Wall Prep

Recommended Minimum Drywall Finish


**5** White blanco



**DO NOT TINT PRIMER**  
ZOLATONE PRIMER MUST BE WHITE

Water-soluble stains should be spot primed with Zolatone Primer SP235 prior to general priming.

## B. Mixing



Stir by hand with a gentle rolling motion, box or mix using hand mixer.




**DO NOT USE A MECHANICAL AGITATOR**

## C. Thinning


**SPRAY**

**ONLY IF NECESSARY**




If you think it is necessary to thin your Zolatone product, stop and call customer service. You will be helped by Technical Service. **1-800-765-6699**

## Equipment




ELECTRONIC OR GLYCERIN PRESSURE GAUGE AT THE MANIFOLD OUTLET




AIRLESS SPRAY UNIT .54 GPM  
GRACO ULTRAMAX 495  
MINIMUM UNIT REQUIREMENT


SPRAY TIP LTX 517- 519  
(0.017 - 0.019)



50' x 1.4"/MAX 3300 PSI  
AIRLESS GUN & HOSE



REMOVE FILTERS



INSTALL MESH SOCK




## I. First Coat



WORKING PRESSURE  
1300 - 1500

To avoid hard lines, feather beginning and end of strokes.




Application Speed



Spraying too rapidly may result in a non-uniform appearance.

## 1 COAT = 2 PASSES

1st PASS (paso) - Horiz. 2nd PASS (paso) - Vert.



50% overlap.




DRY TO TOUCH




## 2. Second Coat

To avoid hard lines, feather beginning and end of strokes.



1st PASS (paso) - Horiz. 2nd PASS (paso) - Vert.



50% overlap.

Application Speed



Spray with slightly faster stroke

## Trouble Shooting

- 1 Wall Does Not Match Jobsite Standard: Without a white primed surface, and 2 cross-lapped coats of Counterpointe the wall will not match the jobsite standard, and the integrity and reparability of the Zolatone product is compromised. Always use the 3 step system. Job Site/architectural submittal is the standard to match.
- 2 Mottled or blotchy finish: This is the result of the run pump pressure set higher than 1500 psi. Reprime and respray areas showing blotchy of mottled appearance.
- 3 Fan lines: To avoid noticeable and abrupt fan lines at the end of your spray stroke, release trigger before finishing your spray stroke, feathering the material out beyond typical stroke span.

## Visit [www.zolatone.com](http://www.zolatone.com) for more information

All settings represent working pressures (i.e., when the gun is triggered). The true measure of proper equipment settings is in the final result on the wall. Pressures shown above are guidelines. Your actual settings may vary due to equipment differences, temperature of the material, environment and the work height.

For complete product data sheets, guide specs, LEED compliance and MSDS visit [www.zolatone.com](http://www.zolatone.com) or call 1-800-765-6699



If you are not clear on any part of this application, **STOP and call! 1-800-765-6699**

© 2008 Master Coating Technologies  
Master Coating Technologies is a member of the USGBC and the CaGBC  
MCT Corporate Offices:  
2777 Eagandale Boulevard  
Eagan, MN 55121

**zolatone**