

# SP203 Sealing Primer

## PRODUCT DATA SHEET



### FINISH DESCRIPTION

#### SP203 / Waterbase Sealing Primer

SP203 is a high quality, waterbased, sealing drywall primer. SP203 has been formulated with an acrylic resin to provide excellent adhesion over new or previously painted drywall, plaster and smooth masonry. All Zolatone primers are designed to be used in conjunction with Zolatone finishes. All Zolatone finishes require a white untinted primer to ensure coverage, color accuracy and performance characteristics.

#### Interior Surfaces

- New or previously painted surfaces
- Drywall / Gypsum Board / Plaster / Smooth Masonry

### TECHNICAL DATA & CHARACTERISTICS

<b>Color</b>	White DO NOT TINT (All Zolatone finishes require white untinted primer)
<b>Coverage Rate:</b>	250 - 350 sq ft / gal depending on surface porosity, texture and application
<b>Dry Time:</b>	Touch: 30 minutes, Recoat: 1-2 hours
<b>Dry Film Thickness:</b>	Average 1 - 1.5 mils.
<b>Solids by Volume:</b>	34%
<b>Weight per Gallon:</b>	11.62 lbs.
<b>Specular Gloss:</b>	Flat (@ 60° angle).
<b>DOT Shipping Class:</b>	Not regulated
<b>VOC Content:</b>	60 g/L
<b>Service Temp:</b>	Min. 50°F Max. 85°F
<b>Flash Point:</b>	Not applicable
<b>Caution:</b>	Protect from freezing. Do not apply when temperature of paint or surface is below 50° F.

### SURFACE PREPARATION

#### General Surface Preparation

All surfaces must be clean, free of dust, chalk, oil, grease, wax, polish, mold and mildew stains, loose and peeling paint, rust, and all other foreign substances. Adhesion and substrate compatibility is sole responsibility of the contractor and painter.

**New Drywall:** All drywall surfaces should be sufficiently sanded smooth. Remove any remaining drywall dust prior to priming. Allow all drywall compounds to be completely dry prior to coating.

**Previously Painted Drywall:** Remove all loose and peeling paint and all other foreign substances. Ensure surface is clean and free from debris and is ready for primer.

**New Plaster:** New plaster should be thoroughly dry and cured for a minimum of 30 days before painting. When cured, ensure surface has been properly cleaned and is ready for primer.

**Previously Painted Plaster:** Remove all loose and peeling paint and all other foreign substances. Ensure surface is clean and free from debris and is ready for primer.

**Masonry:** All masonry surfaces must be cured at least 30 days before painting. Smooth masonry might require a profile for adhesion.

## APPLICATION INFORMATION

<b>Method</b>	Spray applied - Airless Equipment or Conventional Equipment. Apply only when surface temperature is above 50°F. Only use when humidity is below 50% or humidity is above 85% may prevent product from forming a continuous film and may result in poor adhesion.
<b>Tinting</b>	Do not tint primer.
<b>Thinning</b>	Not required. If absolutely necessary reduce with a slight amount of water. Be careful not to over-thin, as a loss of hide and longer dry time will result.

## DISCLAIMER

No Warranty: We cannot reasonably anticipate or control the many different and varying conditions, or methods by which, this label information and our product may be used. Therefore, we do not guarantee the applicability of this label information or the suitability of this label information or the suitability of this product in any situation. All purchasers and users of this product are hereby put on notice that advice provided over-the-counter is not a warranty and is not to be relied upon, and further that no one is authorized to make any representations or warranties relative to this product. This product is sold WITHOUT WARRANTY, expressed or implied, any claim of any kind is limited to the purchase price of this product.



Zolatone Interior Finishes  
2777 Eagandale Boulevard  
Eagan, MN 55121  
[www.Zolatone.com](http://www.Zolatone.com)  
800.765.6699